


## Boston 6 Seater Garden Dining Set 932581











### BEFORE YOU START

- Retain these instructions for future reference.
- When you are ready to start, make sure that you have the right tools, plenty of space and a clean, dry area for assembly.
- Unwrap all packaging materials and place the components on top of the carton box or on a clean floor to prevent it from scratching.
- Check the pack and make sure you have all the parts listed.
- Ensure that this product is fully assembled as illustrated before use.


### WARNINGS

- Do not stand on the table or the chairs.
- Do not sit on the table.
- Do not overtighten screws or bolts.
- Keep small parts out of reach of children.
- Do not use this product if parts are missing, damaged or worn.
- This product should only be used on firm, level ground.
- Make sure the legs remain in contact with the ground.
- This product is for domestic use only.
- Periodically, inspect and tighten all fixings to ensure the product remains secure.
- Each chair is intended for a maximum weight of 110kg. Do not exceed this weight.


ASSEMBLY INSTRUCTIONS  
Table

 A 1PC	 B 4PCS	 C 4PCS	 D M10 8PCS
 E 4PCS	 F 4PCS	 G 4PCS	 H 1PC


1





2





3






## ASSEMBLY INSTRUCTIONS

### Chair




## ASSEMBLY INSTRUCTIONS


### Parasol




①





②



③





## CARE INSTRUCTIONS

- To clean, wipe with a sponge and warm, soapy water, then wipe with a dry, clean cloth. Do not use solvent-based cleaners or detergents as they can bleach or damage the product.
- Never use a pressure hose or washer to clean the product. Never use scourers, abrasives or chemical cleaners.
- The metal is powder coated. Do not use a wire brush when removing dirt from this item as it may damage the paint leaving the surface open to corrosion.
- Store the furniture in a cool, dry place. Ensure that the furniture is clean and dry before putting into storage.
- We recommend the use of furniture covers to protect your product when not in use.
- Please note, the cushions are not waterproof and should not be left out in the rain. Please store the cushions in a cool, dry place when not in use.
- During bad weather and winter months, the product should be stored in a cool, dry place.
- Periodically check all fixings to ensure none have come loose and re-tighten when necessary.
- When adjusting the parasol, make sure that there is nothing else close to it.
- Take down and put away the parasol in windy or inclement weather.
- Keep the parasol away from fireworks and other flammable materials.
- Children should not assemble or disassemble the parasol without sufficient adult supervision.
- When closing the parasol, its pole must be adjusted to be vertical first.
- Please keep away from sources of extreme heat and naked flames.
- The warranty does not cover accidental damage/neglect or general wear and tear.

---

## CONTACT

---

CUSTOMER SERVICES - EMAIL: [CUSTOMER.SERVICE@DOBBIES.COM](mailto:CUSTOMER.SERVICE@DOBBIES.COM). TELEPHONE NUMBER: 0131 561 6406 OR CONTACT YOUR LOCAL STORE.

DOBBIES GARDEN CENTRES LTD, MELVILLE NURSERY, LASSWADE, MIDLOTHIAN, EH18 1AZ