

Alps mocha 4 seat outdoor dining set 983453



BEFORE YOU START

- Retain these instructions for future reference.
- When you are ready to start, make sure that you have the right tools, plenty of space and a clean, dry area for assembly.
- Unwrap all packaging materials and place the components on top of the carton box or on a clean floor to prevent it from scratching.
- Check the pack and make sure you have all the parts listed.
- Do not use power tools to construct this product.
- Ensure that this product is fully assembled as illustrated before use.

WARNINGS














- Do not sit or stand on the product.
- This product should only be used on firm, level ground.
- Keep small parts out of reach of children.
- Check all screws or bolts are tightened and inspect regularly.
- Do not tighten screws until fully assembled.
- Do not overtighten screws or bolts.
- Do not use this product if parts are missing, damaged or worn.
- This product is for domestic use only.
- Do not place boiling hot items directly onto glass.
- This set includes dining chairs, these chairs have a maximum weight tolerance of 110kg, do not exceed this weight.

DOBBIES INSTRUCTION MANUAL

ASSEMBLY INSTRUCTIONS

PARTS AND FITTINGS SUPPLIED




PARTS LIST											
A	TABLE TOP		1	B	TABLE BASE(1)		2	C	TABLE BASE(2)		2
D	BOLT(M6X25L)		8	E	BOLT(M6X20L)		4	F	NUT(M6)		8
G	METAL WASHER (Φ6.5)		20	H	PLASTIC NUT CAP(M6)		8	I	PLASTIC BOLT CAP(M6)		12
J	GLASS TOP		1	K	PARASOL INSERT		1	L	ALLEN WRENCH		1
M	HEX WRENCH		1								

STEP 1:


Remove Glass Top (J) and place Table Top (A) face down on a flat, soft area of ground. Attach Table Base 1 (B) to Table Top (A) using Bolts (E) and Metal Washers (G). Repeat for second Table Base 1 (B).

Note: Plastic Bolt Caps (I) should only be added once all bolts have been tightened after Step 2.



STEP 2:

Attach Table Base 2 (C) to Table Base 1 (B) using Bolts (D), Metal Washers (G) and Nuts (F). Metal Washers (G) should go either side of the fixing brackets. Fully tighten all bolts and add Plastic Bolt Caps (I) and Plastic Nut Caps (H). Turn table upright and place Glass Top (J) on Table Top (A), securing with suction cups. Finally insert Parasol Insert (K) into the hole of the Glass top (J).



CARE INSTRUCTIONS

- This product contains tempered safety glass, please handle with extreme care.
- Please keep away from sources of extreme heat and naked flame.
- Please note that synthetic weave product may sag under direct sunlight. This is a normal occurrence and the weave will return to its normal state upon cooling. To help reduce this occurrence, we recommend using a parasol where possible.
- If this table has been bought as part of a set and comes with chairs, please note that the cushions or seat pad must be sponge washed only and left to dry naturally.
- Please ensure any cushions or seat pads are kept away from sources of naked flame.
- Warm soapy water is recommended to clean the product.
- Throughout the winter months, bring product indoors where possible or use a breathable furniture cover. Failure to do so may invalidate your warranty.
- Do not place boiling hot items directly onto glass.
- This set includes dining chairs, these chairs have a maximum weight tolerance of 110kg, do not exceed this weight.
- Please note the cushions are not waterproof and should not be left out in the rain. Please store the cushions in a cool, dry place when not in use.

CONTACT

CUSTOMER SERVICES - EMAIL: CUSTOMER.SERVICE@DOBBIES.COM. TELEPHONE NUMBER:
0131 561 6406 OR CONTACT YOUR LOCAL STORE.
DOBBIES GARDEN CENTRES LTD, MELVILLE NURSERY, LASSWADE, MIDLOTHIAN, EH18 1AZ

