


SWIVEL CHAIR  
359302



## BEFORE YOU START

- Retain these instructions for future reference.
- When you are ready to start, make sure that you have the right tools, plenty of space and a clean, dry area for assembly.
- Unwrap all packaging materials and place the components on top of the carton box or on a clean floor to prevent it from scratching.
- Check the pack and make sure you have all the parts listed.
- Ensure that this product is fully assembled as illustrated before use.

## WARNINGS

- Do not stand on the product.
- Do not overtighten screws.
- Do not tighten screws until fully assembled.
- Do not use this product if parts are missing, damaged or worn.
- Keep small parts out of reach of children.
- This product should only be used on firm, level ground.
- Make sure the legs remain in contact with the ground.
- This product is for domestic use only.
- Periodically, inspect and tighten all fixings to ensure the product remains secure.
- This product is intended for a maximum weight of 110kg. Do not exceed this weight.

## ASSEMBLY INSTRUCTIONS


## PARTS SUPPLIED

REF	DESCRIPTION	QUANTITY	ILLUSTRATION
A	Chair Frame	X1	
B	Chair Base	X1	
C	Rotating Disc	X1	
D	Screw	X8	
E	Washers	X8	
F	Seat Pad	X1	
G	Allen key	x1	

## ASSEMBLY IMAGES &amp; STEPS


## Step 1

Attach the Rotating Disc (C) to the top of the Chair Base (B) using the washers (E) and screws (D). Please ensure the disc is the correct orientation before screwing.




## Step 2

Connect the top of the Chair Base (B) to the bottom of the Chair Frame (A) by aligning the holes in the centre of both parts and attaching using washers (E) and screws (D) as shown.



## Step 3

Please the Seat Pad (F) into the Chair Frame (A).



## CARE INSTRUCTIONS

- To clean, wipe with a sponge and warm, soapy water, then wipe with a dry, clean cloth. Do not use solvent-based cleaners or detergents as these will damage the look of the product.
- Never use a pressure hose or washer to clean the product. Never use scourers, abrasives or chemical cleaners.
- The metal is powder coated. Do not use a wire brush when removing dirt from this item as it may damage the paint leaving the surface open to corrosion.
- Store the furniture in a cool, dry place. Ensure that the furniture is clean and dry before putting into storage.
- We recommend the use of furniture covers to protect your product when not in use.
- Please note, the cushions are not waterproof and should not be left out in the rain. Please store the cushions in a cool, dry place when not in use.
- During bad weather and winter months, the product should be stored in a cool, dry place.
- Periodically check all fixings to ensure none have come loose and re-tighten when necessary.
- Please keep away from sources of extreme heat and naked flames.
- The warranty does not cover accidental damage/neglect or general wear and tear.